



Separation of Acetone and Water using solvent 3-Methylhexane

Name: - Pratik Rathod

Institute:- G. H. Patel College of Engineering & Technology

Background:-

Acetone is an organic compound with the formula C₃H₆O. It is a colorless, highly volatile and flammable liquid with a characteristic pungent odor. Acetone is miscible with water and serves as an important organic solvent in industry, home, and laboratory. Acetone is most commonly used in pharmaceuticals to producing pills and liquid medicines to have proper density. Acetone denatures certain alcohol and is used as an additive in makeup and skin creams. One of the primary ingredients of nail paint remover is acetone.

3-Methylhexane is an organic compound with the formula C₇H₁₆. 3-Methylhexane is an alkane and a volatile organic compound. It is a colorless liquid with a gasoline-like odor and is commonly used as a solvent in various industries such as pharmaceutical, chemical, and polymer. It is primarily produced through the catalytic hydrogenation of linear or branched aldehydes or ketones.

Description:-


A feed mixture consisting of Acetone and Water is fed to the Extractive Distillation column at 25 °C and 1 bar with a flowrate of 100 kg/h. Solvent 3-Methylhexane is also fed to the Extractive Distillation column at 30 °C and 1 bar with a flowrate of 150 kg/h. Extractive Distillation column has 32 stages with Condenser and Reboiler at 1 bar pressure.





In Extractive Distillation column, Water is separated from Acetone and obtained from the bottom of the column. The top product (Acetone and 3-Methylhexane) is sent to the Simple Distillation column (Solvent Recovery column) for further separation where pure Acetone is obtained from the top of the column and 3-Methylhexane is obtained from the bottom of the column at 95.7 °C which is cooled by cooler at 25 °C & recycled to the solvent recovery stream for reuse.

Flowsheet:-







DWSIM Flowsheeting Project

Result:-

| Master Property Table | | | | | | | | | | |
|--|-------------|------------------|-------------|-------------|-------------|-------------|-------------|------------|----------------|-----------|
| Object | Water | Solvent Recovery | S-03 | S-02 | S-01 | Make-up | Feed | Acetone | 3-Methylhexane | |
| Temperature | 12.3335 | 25 | 25 | 61.0551 | 25.0011 | 25 | 25 | 57.7331 | 95.7602 | С |
| Pressure | 1.01325 | 1.01325 | 1.01325 | 1.01325 | 1.01325 | 1.01325 | 1.01325 | 1.01325 | 1.01325 | bar |
| Mass Flow | 20.0582 | 173.272 | 173.272 | 389.252 | 309.31 | 150 | 100 | 215.979 | 173.272 | kg/h |
| Molar Flow | 1.06482 | 2.80861 | 2.80861 | 5.61721 | 4.05372 | 1.49698 | 2.62831 | 2.80861 | 2.80861 | kmol/h |
| Volumetric Flow | 0.0201646 | 0.215989 | 0.215989 | 0.526433 | 0.410688 | 0.219095 | 0.113715 | 0.304737 | 0.231667 | m3/h |
| Density (Vapor) | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | kg/m3 |
| Molecular Weight (Vapor) | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | kg/kmol |
| Dynamic Viscosity (Vapor) | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | Pa.s |
| Heat Capacity (Vapor) | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | kJ/[kg.K] |
| Compressibility Factor (Vapor) | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Molar Fraction (Vapor) | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Mass Fraction (Vapor) | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Volumetric Fraction (Vapor) | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Density (Liquid 1) | 994.725 | 802.227 | 802.227 | 739.414 | 753.15 | 684.636 | 879.388 | 708.74 | 747.936 | kg/m3 |
| Molar Weight (Liquid 1) | 18.8371 | 61.6934 | 61.6934 | 69.2963 | 76.3027 | 100.202 | 38.0472 | 76.8992 | 61.6934 | kg/kmol |
| Dynamic Viscosity (Liquid 1) | 0.00122402 | 0.000605165 | 0.000605165 | 0.000293164 | 0.000507337 | 0.000347326 | 0.000602427 | 0.00025203 | 0.000233766 | Pa.s |
| Heat Capacity (Liquid 1) | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | kJ/[kg.K] |
| Molar Fraction (Liquid 1) | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| Mass Fraction (Liquid 1) | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| Volumetric Fraction (Liquid 1) | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| Molar Fraction (Vapor) / Acetone | 2.12621E-12 | 1.07349E-12 | 1.07349E-12 | 0.731687 | 6.69034E-13 | 0 | 0.897742 | 0.754535 | 4.7154E-13 | · |
| Molar Fraction (Liquid 1) / Acetone | 9.39876E-15 | 2.19234E-14 | 2.19234E-14 | 0.233952 | 1.77051E-14 | 0 | 0.5 | 0.467904 | 2.19234E-14 | |
| Molar Fraction (Vapor) / Water | 0.97027 | 0.253471 | 0.253471 | 0.0630818 | 0.136373 | 0 | 0.102258 | 0.0127444 | 0.402308 | |
| Molar Fraction (Liquid 1) / Water | 0.99 | 0.46855 | 0.46855 | 0.256136 | 0.290792 | 0 | 0.5 | 0.0437225 | 0.46855 | |
| Molar Fraction (Vapor) / 3-methylhexane | 0.0297297 | 0.746529 | 0.746529 | 0.205231 | 0.863627 | 1 | 0 | 0.232721 | 0.597692 | |
| Molar Fraction (Liquid 1) / 3-methylhexane | 0.01 | 0.53145 | 0.53145 | 0.509912 | 0.709208 | 1 | 0 | 0.488374 | 0.53145 | _ |